



Installation Instructions--Racingline 07+ Altima / 09+ Maxima Strut Bar #18651

Included Items

- 2 Strut Bar Brackets
- 2 x 8mm bolts
- 2x 10 mm nuts
- 1x Strut Bar
- 2x 10mm bolts

Tools Needed:

- 13mm, 15mm wrench
- 13mm, 15mm sockets
- Ratchet



1. Remove (3) 13mm bolts located on top of strut tower. Be careful not to move the car as the strut could slide out of place.

*****If the strut holes shift you will need to lift the effected corner with a jack to realign the holes. Your vehicle alignment settings will not be affected.** ***



2. Place the Racingline strut bar bracket on top of the tower, and begin to thread bolt #2. **Only turn a few threads, DO NOT tighten completely at this point.**

3. With bolt #2 partially threaded, begin to thread bolt #2 and bolt #3(using supplied 8mm bolt). Again do not fully tighten any bolts.



4. With both brackets loosely in place, install the bar portion using the 10mm bolts and nuts supplied. This will now ensure that the brackets properly align to the correct position and are straight.



5. You may now proceed to tighten the remaining bolts and finish the installation

***Maxima users will need to trim the plastic access covers if they wish to reinstall them. Altima's are not supplied with the plastic covers.**