



## RacingLine Ypipe Installation

### Included items

- 1 Y Pipe

### Tools needed (application may vary slightly)

- Misc sockets
- Ratchet

1. Safely raise and support vehicle
2. Remove 3x 14mm nuts on each bank of the OEM Ypipe. ( 6 in total)



3. Remove 2x 14mm bolts from rear of OEM ypipe
4. With the pipe now removed, you should either transfer over the OEM crush gaskets to the new YPipe or install news ones.



5. Line the pipe back up to the flanges and bolt it in
6. Check for leaks and enjoy!



**These Instructions are available online @ [www.RacinglinePerformance.com](http://www.RacinglinePerformance.com)**